

MEMBRA® Cuff for Floor on Roll

Cuff for Membra® membrane system

Description :

Membra Drain Collar consists of PE foam and butyl adhesive protected by a silicone-treated tear-off foil



Application :

Membra Drain Collar Universal roll is part of the Membra Wet Room System. The product is used to achieve a robust and waterproof seal with drain gratings and other drains of non-standard dimensions. The gasket offers excellent adhesion to solid substrates such as concrete, screed, plasterboard etc.

Storage :

Dry and protected from UV

Approvals and guarantee



Installation :

Cut the Membra Drain Gasket Universal to fit the relevant drain and install it by removing the locking system on the drain. Then remove the protective foil so that the gasket can be fitted in the drain and stuck well to the substrate. Use a profiling tool to stick the gasket down firmly. Finally, fit the locking system back on to the drain. See separate installation instructions.

NB: The substrate must be firm, clean, dry and free from grease. Always prime the floor first with Membra Adhesive Primer.

For more details see laying instruction on our website.

Accessories for :

MEMBRA® Membranduk

MEMBRA® Cuff for Floor on Roll⁶²⁰⁶⁰⁴

Product data	Value	Designation
Thickness	0,95	mm
Width	320	mm
Length in mm	5000	mm
Material	PE foam	-

