EN 2022.11.14 Page 1/2

Sanitary Vent 15-50°

Ventilation cowl for 15-50° shingle roof

Description:

The cowl has insulated pipes for connection to ventilation directed over the roof. The ventilation cowl has an adjustable socket that can be cut to fit 100–160 mm pipe diameters. The profile is adapted to Isola Roofing Shingles.



Application:

Used for heat recovery systems or other mechanical ventilation

Storage:

When storing in sunlight, the ventilation hood must be unpacked from the plastic.

Installation:

Install the roofing shingles up to the front edge of the ventilation cowl. Fit the ventilation cowl. Apply two strips of Isola Sealant, then place the roofing shingles on the collar of the ventilation hood. See separate installation instructions.

Fore more details see laying instruction on our website.

Accessories for:

Isola Kraftunderlag1x10m

Approvals and guarantee





Sanitary Vent 15-50°

Product data	Value	Designation
Material	Hette og adapter: High Impact Polystyren Isorør: EPS	-
Maks takvinkel	45	0
Min roof angle	15	0

Product number	Color
567224	Brick red
567201	Slategrey
567213	Black
567209	Antiquebrown



